

1 Accessories, 858 Series

98

Holding bracket



Description	Item No.	Pack. unit
Holding bracket for industrial relays (height 33.5 mm ... 35.5 mm)	858-110	1

Push-in type jumper bar



Description	Item No.	Pack. unit
Push-in type jumper bar	858-402	200

Status indication



Description	Power consumption at V_N	Item No.	Pack. Unit
Status indication 24 V DC (12 V ... 24 V)	2.4 mA	788-120	50 (2x25)
Status indication 48 V DC (48 V ... 60 V)	1.9 mA	788-121	50 (2x25)
Status indication 110 V DC	1.9 mA	788-122	50 (2x25)
Status indication 24 V AC	2.1 mA	788-123	50 (2x25)
Status indication 115 V AC	1.7 mA	788-124	50 (2x25)
Status indication 230 V AC	1.6 mA	788-125	50 (2x25)

NOTE:

Only required when using relays without integrated operating indicator!

Operating tool



Description	Item No.	Pack. unit
Operating tool, with partially insulated shaft	Type 2, blade (3.5 x 0.5) mm	210-720