

# Rittal – The System.

Faster – better – everywhere.

## ► Assembly instructions for Ri4Power low- voltage switchgear for Form 1-4, with Flat- PLS, Maxi-PLS and RiLine – SV 9676.000

Date : Mar 17, 2014

ENCLOSURES

POWER DISTRIBUTION

CLIMATE CONTROL

IT INFRASTRUCTURE


SOFTWARE & SERVICES

FRIEDHELM LOH GROUP



# Assembly instructions for Ri4Power low-voltage switchgear for Form 1-4, with Flat-PLS, Maxi-PLS and RiLine – SV 9676.000

created : 17.03.2014 on [www.rittal.com/com-en](http://www.rittal.com/com-en)



## Product description

### Description:

- These assembly instructions explain the configuration of type-tested Ri4Power field types and possible busbar systems, divided into 3 sections. The first section explains the assembly sequence for the individual stages of the possible field types in diagrammatic form. The second section provides detailed assembly instructions using diagrams and data tables. The final section explains the installation of optional accessories and general work operations. This documentation is available for downloading at the Rittal website [www.rittal.com](http://www.rittal.com) under "Download brochures". Alternatively, a printed copy may be ordered quoting the following item number.

### Packs of:

- 1 pc(s).

### EAN:

- 4028177642911

### Customs tariff number:

- 49119900

# Rittal – The System.

---

**Faster – better – everywhere.**

- Enclosures
- Power distribution
- Climate Control
- IT Infrastructure
- Software & services

Rittal GmbH & Co. KG  
Postfach 1662 · D-35726 Herborn  
Phone: +49 (0) 2772 505-0 · Fax: +49 (0) 2772 505-2319  
E-Mail: [info@rittal.com](mailto:info@rittal.com) · [www.rittal.com](http://www.rittal.com)

ENCLOSURES

POWER DISTRIBUTION

CLIMATE CONTROL

IT INFRASTRUCTURE

SOFTWARE & SERVICES



FRIEDHELM LOH GROUP