# Product data sheet Characteristics

# ATS22C41Q soft starter-ATS22-control 220V-power 230V(110kW)/400...440V(220kW)

Main	
Commercial Status	Commercialised
Range of product	Altistart 22
Product or component type	Soft starter
Product destination	Asynchronous motors
Product specific appli- cation	Severe and standard applications
Component name	ATS22
Network number of phases	3 phases
Power supply voltage	230440 V (- 1510 %)
Motor power kW	220 kW at 440 V 220 kW at 400 V 110 kW at 230 V
Factory setting current	388 A
Power dissipation in W	177 W for standard applications
Utilisation category	AC-53A
Type of start	Start with torque control (current limited to 3.5 ln)
Icl nominal current	410 A (connection in the motor supply line) for stan- dard applications
IP degree of protection	IP00

# Complementary

With heat sink	
Internal bypass	
195484 V	
5060 Hz (- 1010 %)	
4566 Hz	
In the motor supply line To the motor delta terminals	
220230 V -1510 % at 50/60 Hz	
20 W	
2	
(R2)Relay outputs 230 V running, alarm, trip, stopped, not stopped, starting, ready, C/O (R1)Relay outputs 230 V running, alarm, trip, stopped, not stopped, starting, ready, C/O	
Relay outputs 100 mA at 12 V, DC	
Relay outputs 2 A at 30 V, DC inductive load, L/R = 7 ms Relay outputs 2 A at 250 V, AC inductive load, cos phi = 0.4, L/R = 20 ms Relay outputs 5 A at 30 V, DC resistive load, cos phi = 1 Relay outputs 5 A at 250 V, AC resistive load, cos phi = 1	
3	
(LI1, LI2, LI3)logic 5 mA 4.3 kOhm	
24 V (<= 30 V)	
(LI1, LI2, LI3)positive logic state 0 < 5 V and < 2 mA state 1 > 11 V and > 5 mA	
0.41 Icl adjustable	
750 Ohm	
Modbus	
1 RJ45	
Serial	



Physical interface	RS485 multidrop	
Transmission rate	4800, 9600 or 19200 bps	
Max nodes number	31	
Protection type	Thermal protection on starter Thermal protection on motor Phase failure on line	
Marking	CE	
Type of cooling	Forced convection	
Operating position	Vertical +/- 10 degree	
Height	425 mm	
Width	206 mm	
Depth	299 mm	
Product weight	33 kg	

#### Environment

Electromagnetic compatibility	Voltage/Current impulse conforming to IEC 61000-4-5 level 3	
	Immunity to radiated radio-electrical interference conforming to IEC 61000-4-3 level 3	
	Immunity to electrical transients conforming to IEC 61000-4-4 level 4	
	Electrostatic discharge conforming to IEC 61000-4-2 level 3	
	Damped oscillating waves conforming to IEC 61000-4-12 level 3	
	Conducted and radiated emissions conforming to IEC 60947-4-2 level A	
Standards	EN/IEC 60947-4-2	
Product certifications	CCC	
	CSA	
	C-Tick	
	GOST	
	UL	
Vibration resistance	1.5 mm (f = 213 Hz) conforming to EN/IEC 60068-2-6	
	1 gn (f = 13200 Hz) conforming to EN/IEC 60068-2-6	
Shock resistance	15 gn for 11 ms conforming to EN/IEC 60068-2-27	
Noise level	56 dB	
Pollution degree	Level 2 conforming to IEC 60664-1	
Relative humidity	<= 95 % without condensation or dripping water conforming to EN/IEC 60068-2-3	
Ambient air temperature for operation	> 40< 60 °C with current derating 2.2 % per °C	
	-1040 °C without derating	
Ambient air temperature for storage	-2570 °C	
Operating altitude	> 1000< 2000 m with current derating of 2.2 % per additional 100 m <= 1000 m without derating	

# **RoHS** compliance

RoHS EUR status	Compliant
RoHS EUR conformity date(YYWW)	0939

# Contractual warranty

Period


18 months

# Product data sheet Dimensions Drawings

# ATS22C41Q

# Frame Size E

#### Dimensions



# ATS22C41Q

#### Precautions

#### Standards

The Altistart 22 soft starter is compliant with pollution Degree 2 as defined in NEMA ICS1-1 or IEC 60664-1.

For environment pollution degree 3, install the Altistart 22 soft starter inside a cabinet type 12 or IP54.


A DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

ATS22 soft starters are open devices and must be mounted in a suitable enclosure. Failure to follow these instructions will result in death or serious injury.

#### Air Circulation

Leave sufficient free space to help the air required for cooling purposes to circulate from the bottom to the top of the unit.



#### Overheating

To avoid the soft starter to overheat, respect the following recommendations:

- Mount the Altistart 22 Soft Starter within ± 10° of vertical.
- Do not locate the Altistart 22 Soft Starter near heat radiating elements.
- Electrical current through the Altistart 22 Soft Starter will result in heat losses that must be dissipated into the ambient air immediately surrounding the soft starter. To help prevent a thermal fault, provide sufficient enclosure cooling and/or ventilation to limit the ambient temperature around the soft starter.
- If several soft starters are installed in a control panel, arrange them in a row. Do not stack soft starters. Heat generated from the bottom soft starter can adversely affect the ambient temperature around the top soft starter.

#### Wall mounted or Floor-standing Enclosure with IP 23 Degree of protection

#### Introduction

To help proper air circulation in the soft starter, grilles and forced ventilation can be installed.

Ventilation Grilles




Forced Ventilation Unit




# ATS22C41Q

# **Power Terminal**

### Bar Style





Power supply and output to motor	Bar	b	30 mm (1.18 in)
а	5 mm (0.2 in)		
Bolt	M12 (0.47 in)		
Cable and protective cover	Size	2X150 mm <sup>2</sup>	
Gauge	2X250 MCM		-
Protective cover	LA9F703		
Tightening torque	57 N.m		
498.75 lb.in		_	


# Power connections, minimum required wiring section

IEC cable	UL cable
mm² (Cu 70°C/158°F) (1)	AWG (Cu 75°C/167°F) (1)
2 X 150	2 X 250 MCM

## 230 Vac control, logic Inputs (LI) 24 Vdc, 3-wire control

#### With Line Contactor, Freewheel or Controlled Stop Q1 230V (2) Q1 KM1 \$10fo-Q3 S2 F-11 11 10 CL1 3/12 KM' 20 5AL3 PTC2 101 ſ NO KM1 8 ⊕ RIA 22B 220 22A 5 2 84 E--83 E-3

230 Vac control, logic Inputs (LI) 24 Vdc, 2-wire control, freewheel stop




### Connection in the motor delta winding in series with each winding

#### Wiring

ATS22 soft starters connected to motors with the delta connections can be inserted in series in the motor windings.

The following wiring requieres particular attention. It is documented in the Altistart 22 Soft start - soft stop unit user manual. Please contact Schneider Electric commercial organisation for further informations.




#### Example

A 400 V - 110 kW motor with a line current of 195 A (nominal current for the delta connection). The current in each winding is equal to 195/1.5 or 130 A. The rating is determined by selecting the soft starter with a permanent nominal current (ICL) just above this current.

# Product data sheet Performance Curves

# ATS22C41Q

## Motor Thermal Protection - Cold Curves



Trip time for a Standard Application (Class 10)

3.5 In	
32 s	

# Trip time for a Severe Application (Class 20)


3.5 ln	
63 s	

# Trip time for a Severe Application (Class 30)

3.5 ln	
95 s	

#### Motor Thermal Protection - Warm Curves

#### Curves



Class 30

## Trip time for a Standard Application (Class 10)

3.5 ln			
16 s			

## Trip time for a Severe Application (Class 20)

3.5 ln	
32 s	

# Trip time for a Severe Application (Class 30)

3.5 ln	
48 s	